







Installing the A34956 Hydraulic Quick Attachment Coupling Plate.

The component and parts of the listing below, will be needed to accomplish the installation of the electro-hydraulic quick attachment coupling plate.

The parts of the standard booms will be replaced accordingly.

The spare-part number of the corresponding mechanically operated attachment plate is: A34362

Mounting of the switch belongs to the middle of the dash at the right side.

A417431 Hydraulic hose L = 5600 and A411379 Hydraulic hose L = 400 Must be joined together, it makes one hose.

The installation the A34747 power pack shall be made behind the self leveling cylinder at the front frame.

The hydraulic oil for the power pack must be chosen ISO VG 32 type.

When mounting on the power pack, the hydraulic system must first be thoroughly bleeded from all possible air bubbles.

The wire harness A34902 must be fitted behind a 25A fuse, at the fuse panel.





