



Fork5 ASENNUSOHJE

1. Levitä ketju maahan. Aseta ketju renkaan päälle niin, että sisälukko on sisäpuolella ja ulkolukko ulkopuolella. Aja ajoneuvoa eteenpäin, kunnes ketju on kiinnitettävissä.

2. Kytke ensin sivukettinki sisälukolla mahdollisimman kireälle.



3. Kytke sitten ulkolukko mahdollisimman kireälle.



4. Kiinnitä "irallinen" poikkikettinki sakkelilla sivukettinkiin. EI KOUKKUUN!



5. Aja muutama metri ja tarkista ketjujen kireys. Kiristä tarvittaessa.



Fork5 Mounting Instruction

1. Spread the chain to the ground. Position the chain on the tire the inside fastener (the smaller one) on the inner side and the outside fastener (the bigger one) on the outer side of the lock. Turn the wheel by moving the vehicle with the chain forward until the ends of the chain meet each other.

2. Connect the inside fastener (the smaller one) as tight as possible.



3. Connect the outside fastener (the bigger one) as tight as possible.



4. Connect the cross chain with shackle to the side chain. NOT TO HOOK!



5. Drive with the newly installed chains for just a couple of meters and adjust the tightness if needed